

Pultsetup

INPUT LAYER

CH	Instr	Mic	Mute Gruppe	VCA / Gruppe	Beschreibung
1	KCK	D6	1,2	1	-
2	SN	D2	1,2	1	-
3	HH	C391	1,2	1	-
4	Bongo1	D2	1,2	1	-
5	Bongo2	D2	1,2	1	-
6	TOM1	D2	1,2	1	-
7	TOM2	D2	1,2	1	-
8	FT1	D2	1,2	1	-
9	FT2	D2	1,2	1	-
10	OH L	C391	1,2	1	-
11	OH R	C391	1,2	1	-
12	BASS DI	BSS 133	1,3	2	-
13	BASS	SM 57	1,3	2	-
14	GIT	e906	1,3	2	-
15	GIT add	SM 57	1,3	2	-
16	LEAD VOC	Beta 58A	1	3	-
17	BACK VOC	SM 58	1	3	-
18	PC L	BSS 133	1	-	Zuspieler
19	PC R	BSS 133	1	-	Zuspieler
20	Voc Hall	-	1,4	-	Return
21	Delay	-	1,4	-	Return
22	Room	-	1,4	-	Return

OUTPUT LAYER

CH	INSERT	Beschreibung
AUX 1	31 Band EQ	Monitoring Gitar
AUX 2	31 Band EQ	Monitoring Voc
AUX 3	31 Band EQ	Monitoring Bass
AUX 4	31 Band EQ	Monitoring Drums
Delay Line	31 Band EQ	Delay Line / Nearfill
C / Subs	31 Band EQ	Center / Nearfill / Subs
L	31 Band EQ	Summe Links
R	31 Band EQ	Summe Rechts

Mikroliste

NAME	STK	Alternative
------	-----	-------------

Audix D2	7	Sennheiser e604
Audix D6	1	-
AKG C391	3	Neuman KM 184 / DPA 2011C
Sennheiser e906	1	Shure SM 57
Shure SM57	2	-
Shure SM58	1	-
Shure 58 Beta	1	-
BSS 133	3	-